

The following table provides watts loss data for Fuji Electric's **FRENIC-Mini** series drives.

FRENIC-Mini				
Voltage	Hp	Drive Model Number	Drive Watts Loss	
			Low carrier frequency	High carrier frequency
Three-phase 230VAC	1/8	FRNF12C1S-2U	20	23
	1/4	FRNF25C1S-2U	27	32
	1/2	FRNF50C1S-2U	40	50
	1	FRN001C1S-2U	60	77
	2	FRN002C1S-2U	91	110
	3	FRN003C1S-2U	128	165
Three-phase 460VAC	1/2	FRNF50C1S-4U	28	45
	1	FRN001C1S-4U	41	64
	2	FRN002C1S-4U	63	103
	3	FRN003C1S-4U	89	149
	5	FRN005C1S-4U	135	235
Single-phase 230VAC	1/8	FRNF12C1S-7U	21	24
	1/4	FRNF25C1S-7U	29	34
	1/2	FRNF50C1S-7U	41	51
	1	FRN001C1S-7U	64	80
	2	FRN002C1S-7U	101	129
	3	FRN003C1S-7U	143	180

Note:

The carrier frequency is programmable, via parameter F26, see the FRENIC-Mini instruction manual INR-SI47-1205-E for additional information.